


| | |
|---------|-------|
| maat 39 | |
| maat 38 | 24 cm |
| maat 37 | 23 cm |
| maat 36 | 22 cm |
| maat 35 | 21 cm |
| maat 34 | 20 cm |
| maat 33 | 19 cm |
| maat 32 | 18 cm |
| maat 31 | 17 cm |
| maat 30 | 16 cm |
| maat 29 | 15 cm |
| maat 28 | 14 cm |
| maat 27 | 13 cm |
| maat 26 | 12 cm |
| maat 25 | 11 cm |
| maat 24 | 10 cm |
| maat 23 | 9 cm |
| maat 22 | 8 cm |
| maat 21 | 7 cm |
| maat 20 | 6 cm |
| maat 19 | 5 cm |
| maat 18 | 4 cm |
| maat 17 | 3 cm |
| maat 16 | 2 cm |



The NicoNico kids size guide

To check whether your printer has not enlarged or reduced the measuring bar, a centimeter measure is shown on the right, which you can compare with a measuring bar.

Place your child's foot with the heel at the indicated location and measure to the very tip of the longest (big) toe. The heel protrudes slightly above the ground, take this into account. If you are in between 2 sizes suit you take the largest size. Children tend to pull their toes in, then gently press them down or let the child wiggle back and forth on their feet for a moment.